



Product indicated for indoor areas.

- 1° - Pass the electrical wire through the central hole.
- 2° - Fix the Support on the ceiling with bushings and screws.
- 3° - Instal the electrical network

- 4° - Align the Body Pin with the Support Gap
- 5° - Fix it and Spin the body to until the pin get the Limiter position.
- 6° - Connect the lamp on socket.
 For E26 Lamps, put it between the springs before.

- 7° - Support the Holding Ring on the lamp and fit it until hear a click sound.
- To replace the lamp, remove the holding ring. If have difficulty on undocking, use a screwdriver as shown at figure above.

ML-2230	Ø2 2/8" x 4 1/3"	GU10	120/277V	Power Max: 7W	Weight: 0.56 lbs
ML-2231	Ø3" x 5 1/3"	PAR20/BR20	120/277V	Power Max: 7W	Weight: 1.10 lbs

Attention

Follow the instructions to ensure proper and safe operation. We recommend that the installation be done by a qualified professional. Recessed ceiling installation requires rigid support point attachment and special installations require special attachment.

Important

Lamps, transformers, and reactors are not included with the product except as noted. Failure to follow the instructions in the manual could result in accidents and loss of warranty. Do not adjust springs and brackets unless otherwise indicated.
 Warranty: 1 year for product and 5 years for Led and Driver.

Cleaning and Maintenance

Before any action turn off the electric current. Clean only with water dampened flannel, never use chemicals or abrasives. The materials that make up the product are non-toxic.